



M-18IIJ00



No.	Name	spec				
			X	Y	Z	
1	海水进水口(海水泵) Sea water inlet (Suatar pup)	832	236	265	567	需与船厂外部管路连接 To be connected with the external pipeline of the shipyard
2	海水出水口(热交换器) Seawater outlet (heat exchanger)	833	334	223	741	需与鱼厂外部管路连接 To be connected with the external pipeline of the fishery
3	排气口 Exhaust port	DM40	657	261	980	需与厂外部管路连接 To be connected with the external pipeline of the factory
4	发电机出线填料函 Stuffing box		\	\	\	
5	燃油出油口 Fuel outlet	86	390	-211	680	蓄与岛厂外部管路连接 To be connected with the external pipeline of the island factory
6	燃油进油口 Fuel inlet	810	153	-244	795	需与临厂外部管路连接 To be connected with the external pipeline of the adjacent factory

[illegible]

1. 海水进水口 See rete inlet	2. 海水出水口 Searater outlet	3. 排气口 (排气变径) Bahaust port (exhaust reducer)	5. 燃油出油口 Pual outlet	6. 燃油进口 Puel inlet
				
		$\phi 67$ $6 \times \phi 11$ $\phi 123-100$		$\phi 10$